

# Operating Instructions



## Single Loop Controller EC48 & EC96



Rev. 1.00.00  
03/2010

## Table of Contents

<b>1</b>	<b>Introduction.....</b>	<b>3</b>
1.1	Typographical Conventions.....	4
<b>2</b>	<b>General Information.....</b>	<b>5</b>
2.1	Warranty Conditions.....	5
2.2	Installation and safety references.....	5
<b>3</b>	<b>Equipment Implementation .....</b>	<b>6</b>
3.1	Type designation.....	6
3.2	Scope of Delivery .....	6
<b>4</b>	<b>Device construction.....</b>	<b>7</b>
4.1	Dimensions.....	7
4.2	Connection overview.....	7
<b>5</b>	<b>Installation/Dismantling .....</b>	<b>8</b>
<b>6</b>	<b>Electrical connection and operational startup.....</b>	<b>9</b>
6.1	Connection type .....	9
6.2	Connector assignment and basic configuration .....	9
6.2.1	Power Supply .....	9
6.2.2	Measurement inputs .....	10
6.2.3	Control outputs .....	11
6.2.4	Digital outputs.....	11
6.2.5	Connection of Current Transformer .....	11
<b>7</b>	<b>Status displays/Diagnostics.....</b>	<b>12</b>
<b>8</b>	<b>Display and Operation.....</b>	<b>13</b>
8.1	Display .....	13
8.1.1	Immediately after Switch ON .....	14
8.1.2	Base Display.....	14
8.1.3	Alternating Display AMP/OP1 (only EC48).....	14
8.1.4	Alternating Display OP1/OP2 (only EC96) .....	14
8.2	Operation .....	15
8.2.1	Keys .....	15
8.2.2	Function Call by Keys .....	16
<b>9</b>	<b>Change Controller Settings.....</b>	<b>17</b>
9.1	Operation of Parameters .....	17
9.1.1	Change of numeral value.....	17
9.1.2	Select from List of Value .....	18
9.2	Operation Levels .....	19
9.2.1	Level 1 – Standard .....	20
9.2.2	Level 2 - Control .....	21
9.3	Level 3 – Outputs .....	22
9.4	Level 4 – Inputs .....	23
9.5	Level 5 – Information.....	24
<b>10</b>	<b>Functions.....</b>	<b>25</b>
10.1	Set Setpoint Value.....	25
10.2	Activating / Deactivating of Manual Mode.....	26
10.3	Set output percentage.....	27
10.4	Display of Heating Current (only EC48).....	28
10.5	Activating / Deactivating of Soft Start Function.....	29
10.6	PID Auto Tuning Function.....	31

<b>11</b>	<b>Appendix .....</b>	<b>32</b>
11.1	Trouble Shooting .....	32
11.1.1	No Display for All Controllers .....	32
11.1.2	No Display for One Controllers .....	32
11.1.3	Temperature Does Not Rise .....	32
11.1.4	Temperature Too High .....	33
11.1.5	Temperature Not Stable .....	33
11.1.6	Difference in Temperature Display .....	33
11.1.7	Temperature Display - - - - .....	33
11.1.8	Temperature Display □□□□ .....	34
11.2	Value Tables .....	34
11.2.1	Alarm Mode Table .....	34
11.2.2	Sensor Types .....	34
11.3	Cooling Output .....	35
11.4	Version History .....	36

# 1 Introduction

The one zone temperature controller is available as

- controller model EC48 in format 48x48 mm
- controller model EC96 in format 48x96 mm

vor.



Illustration EC48

Illustration EC96

A wide range of applications (hot runners, plastic processing, packaging industry, furnaces and ovens, food processing, dryers, etc.) as well as good price performance ratio characterize this one zone temperature controller.

By the two four-digit seven-segment displays the actual value, setpoint value as well as alarm and status messages are directly readable.

The simple operation by only four keys of the membrane keypad leads the user through clearly structured levels, where the parameters can be individually stipulated.

Not only the power supply of 100 ... 240 VAC, 50/60 Hz is for universal use, but also the measurement inputs can be equipped with different types of thermo couples and resistance thermometers configurable in the controller.

According to the equipment implementation the control outputs are of type relay or 24 VDC.

One alarm output (relay type) offers a complete monitoring of the control process (control of a band, of absolute/relative alarm limits, sensor break).

The PID Auto Tuning Function calculates the control parameters (self optimization).

Two and/or three-point operation, manual mode are important functions available for the control zone.

The robust pluggable plastic casing is easy to mount.

## 1.1 Typographical Conventions

Symbols and conventions are used in this manual for faster orientation for you.



Caution

With this symbol, references and information are displayed which are decisive for the operation of the device.

In case of non-compliance with or inaccurate compliance there can result damage to the device or injuries to persons.



Note

The symbol refers to additional information and declarations, which serve for improved understanding.



Example

With the symbol, a function is explained by means of an example.



Reference

With this symbol, information in another document is referred to.



FAQ

Here FAQ (Frequently Asked Questions) are answered.

Equations

Calculation specifications and examples are represented in this way.

## 2 General Information

### 2.1 Warranty Conditions

This product is subject to the legal warranty time periods for faults or deficiencies in manufacture.

#### Content of Warranty

If a malfunction relatively occurs through the manufacture, the supplier repairs or replaces the nonconforming product, according to their own discretion.

The following repairs do not fall under the warranty and are liable to costs:

- Malfunctions after the legal notice periods have expired.
- Malfunctions caused through operating error of the user (if the device is not operated as described in the manual).
- Malfunctions caused through other devices.
- Changes or damage to the device which do not originate from the manufacturer.

If you wish to use services within the framework of this warranty, please refer to the supplier.

### 2.2 Installation and safety references

Before installation, handling or operation of the device, please read through this operating instructions completely and carefully.

#### Service and repair

This device is maintenance free.

If the device should indicate a fault, you please contact the manufacturer. Customer repairs are not permissible.

#### Cleaning

Employ no water or cleaning agents based on water for the cleaning of the device stick-on labels. You can clean the surface of the devices with a mild soap solution.

#### Storage

If you should not put the device into operation immediately after unpacking, protect it against moisture and coarse dirt.

#### Personnel

The installation of the device may be carried out by qualified personnel only.

#### Wiring

The wiring system must be implemented correctly according to the specifications in this operating manual. All feeds and connecting terminals must be dimensioned for the corresponding amperage. Furthermore, all connections are to be carried out according to the valid VDE Specification and/or the respective national specifications.

Ensure in particular that the AC power supply is not connected with the logic output or the low-voltage input.

#### Overload protection

Secure the power supply of the device and the relay output with a fuse protection or a power circuit-breaker. This protects the printed circuit boards against overcurrent.

#### Environment

Conducting contamination must not reach the proximity of the device connecting terminals in the control cabinet. In order to achieve suitable ambient air conditions, install an air filter in the air inlet of the control cabinet. If the device should be in a condensing environment (low temperatures), install a thermostat-controlled heating unit in the control cabinet.

## 3 Equipment Implementation

### 3.1 Type designation

The equipment of the device is stipulated with the order. The exact specification can be read off on the type designation plate, which is on the casing.

The following equipment implementations are available:


EC48 HTS with current transformer	Relay output Heating: electronic switching output
EC96 HTS	Relay output Heating: electronic switching output
EC96 HSR	Relay output Heating: relay output/closer
EC96 HTS KSR	Relay output Heating: electronic switching output Relay output Cooling: relay output/closer
EC96 HSR KSR	Relay output Heating: relay output/closer Relay output Cooling: relay output/closer

### 3.2 Scope of Delivery

- 1 temperature controller EC\*\* (dependent on equipment implementation)
- 1 CD-ROM with data sheet and operating instructions EC48 & EC96

## 4 Device construction

### 4.1 Dimensions



	Controller type EC48	Controller type EC96
A	48	48
B	48	96
C	8	8
D	91.2	91.5
E	45	90
a	45+0.5	45+0.5
b	45+0.5	93+0.5
c	72	120
d	60	60


All specifications in mm.

### 4.2 Connection overview


The connection overview here indicates all possible connection variants.

The actual connection overview depends on the Equipment Implementation (see chapter 3.1), which is stipulated with the order.

#### Controller type EC48



#### Controller type EC96



HSR	Relay output Heating: relay output/closer
KSR	Relay output Cooling: relay output/closer
HTS	Relay output Heating: electronic switching output
TC	Thermocouple TC
Pt100	Resistance thermometer Pt100
I+/I-	Heating current recording



## 5 Installation/Dismantling

### Unpacking

The device is packed fully-mounted in a robust carton. Check the packaging and then the device for identifiable damage incurred during transit. If damage is identified, then please get in touch with the transportation company.



In the case of damage the device may not be brought into operation.

### Ensuring voltage-free state



Before beginning and during all installation/dismantling work, attention is to be paid that the system, as well as the devices, are de-energized

### Installation location

A device of the protection type IP20 is to be installed in a closed control cabinet.

### Securing

The device has a securing mechanism for installation in a control panel cut out.

### Device exchange



Only controllers of similar type may be exchanged. In case of replacement, it is absolutely necessary to adopt the setting adjustments of the replaced controller.

## 6 Electrical connection and operational startup



The controller may be installed and put into operation by specialist personnel only.  
Before switch-on of the control zones it is to be ensured that the controller is configured for the application. An incorrect configuration can lead to damage to the control section or to injuries to persons.

### 6.1 Connection type

The device is equipped with screwed terminals. The terminals existing on the device are to be taken from the Type designation



The wiring system is implemented on the screwed terminals with the appropriate cable lugs. Cables with a cross section of 0.5 to 1.5mm<sup>2</sup> can be employed.

### 6.2 Connector assignment and basic configuration

The overview here indicates all possible device variants.


The actual assignment depends on the Equipment Implementation (see chapter 3.1), which is stipulated with the order.



#### 6.2.1 Power Supply

Controller Type	EC48	EC96
Power Supply	230 VAC 50/60 Hz	230 VAC 50/60 Hz
Range	100 ... 240 VAC ±10%	100 ... 240 VAC ±10%
		
Power consumption	< 5 VA	< 5 VA

### 6.2.2 Measurement inputs

A thermo couple TC or a resistance thermometer Pt100 can be connected to the measurement input.

Controller Type	EC48	EC96	
Thermocouple TC	<div>9</div> <div>10</div>	<div>9</div> <div>10</div>	



Controller Type	EC48	EC96	
Resistance thermometer Pt100 2-wire	<div>8</div> <div>9</div> <div>10</div>	<div>8</div> <div>9</div> <div>10</div>	
Resistance thermometer Pt100 3-wire	<div>8</div> <div>9</div> <div>10</div>	<div>8</div> <div>9</div> <div>10</div>	

#### Configuration on operational startup



Arrange sensor type for the measurement input.	See chapter 9.4 parameter <code>TYPE</code>
--	---

### 6.2.3 Control outputs

The control outputs are stipulated by the Equipment Implementation.

Controller Type	EC48	EC96
HTS Relay output Heating: electronic switching output		

Activation of SSR (solid state relay) DC 24 V / 20 mA


Controller Type	EC48	EC96
HSR Relay output Heating: relay output/closer	n.a.	
KSR Relay output Cooling: relay output/closer	n.a.	

Rated output current 5 A

Rated voltage 250 VAC (ohmic load)

### 6.2.4 Digital outputs

The digital outputs are realized with relay/closer. The device is designed with 1 alarm output.

Controller Type	EC48	EC96
Alarm 1		

Rated output current 5 A

Rated voltage 250 VAC (ohmic load)

#### Configuration on operational startup

Stipulate alarm output 1	See Chapter9.3
--------------------------	----------------

### 6.2.5 Connection of Current Transformer

The output current can be registered by a current transformer and be used to display the heating current (see chapter 10.4).

Controller Type	EC48	EC96
Connection of Current Transformer		n.a.

## 7 Status displays/Diagnostics

For special operating conditions of the controller a text instead of the actual value is displayed, to point out a probable error.

Display	Probable Reason	Fault Correction
LLLLL	<ul style="list-style-type: none"> <li>Input signal below low limit value</li> </ul>	<ul style="list-style-type: none"> <li>Set a lower value for low limit value</li> </ul>
HHHHH	<ul style="list-style-type: none"> <li>Input signal above high limit value</li> </ul>	<ul style="list-style-type: none"> <li>Set a higher value for high limit value</li> </ul>
-----	<ul style="list-style-type: none"> <li>Sensor break</li> <li>Sensor not connected</li> </ul>	<ul style="list-style-type: none"> <li>Replace sensor</li> <li>Check the sensor is connected correctly</li> </ul>
□□□□	<ul style="list-style-type: none"> <li>Check the sensor connection is not interchanged</li> </ul>	<ul style="list-style-type: none"> <li>Check sensor connection + and –</li> </ul>

At start the controller can show in parameter *ErrC* the following error codes:

Display	Meaning	Fault Correction
0	No error	
1	Memory error	Send controller back to supplier
8	Check the sensor connection is not interchanged	Check sensor connection + and –
16	Sensor break	Replace sensor

See chapter 11.1.

## 8 Display and Operation


### 8.1 Display

The overview here indicates all possible device variants.

The actual assignment depends on the Equipment Implementation (see chapter 3.1), which is stipulated with the order.

**EC48**

AL1	Indicator Alarm 1	
AL2		
AL3		
ST	Indicator Auto Tuning	
RMC		
IN1		
IN2		
OP1	Output Heating Active	
OP2		




Unit
Actual value
Setpoint value
Position indication on value change
Value display (for AMP, OP1 alternatively)

Keys see chapter 8.2.1.

**EC96**

AL1	Indicator Alarm 1	
AL2		
AL3		
ST	Indicator Auto Tuning	
HB		
RMC		
IN1		
IN2		
OP1	Output Heating Active	
OP2	Output Cooling Active	



Actual value
Unit
Setpoint value
Position indication on value change
Value display (for OP1, OP2 alternatively)

Keys see chapter 8.2.1.

### 8.1.1 Immediately after Switch ON

Immediately after switch ON, all segments of the display are light. That identifies that all displays are intact. The following displays appear

- Parameter *Edt n*                      Current controller program version (PSGI)
- Parameter *TYPE*                      J (standard configuration) sensor type measurement input
- Parameter *CYC 1*                      1 (standard configuration) cycle time Heating
- Parameter *ErrC*                      Error status controller (0 = no error; see chapter 7, 9.5)

The display changes to base display.

### 8.1.2 Base Display

In base display

- the preset unit
- actual value and setpoint value (and/or output percentage in manual mode) in the two four-digit seven-segment LED displays
- display in the two-digit seven-segment LED display alternatively for
  - EC48 - current (AMP) and/or display of output percentage (OP1)
  - EC96 - display of output percentage 1 (OP1) and/or display of output percentage 2 (OP2) (dependent on to equipment implementation)

are shown.

### 8.1.3 Alternating Display AMP/OP1 (only EC48)

The display down left alternates all 3 seconds between output percentage and heating current.



Display output percentage for OP1



Display heating current for AMP

### 8.1.4 Alternating Display OP1/OP2 (only EC96)

The display down right alternates all 3 seconds between output percentage 1 OP1 and output percentage 2 OP2 (dependent on equipment implementation)




Display output percentage 1 for OP1



Display output percentage 2 for OP2

## 8.2 Operation

The setpoint value can be changed directly in the base display () . To change the setting of a parameter, choose first the parameter and/or the adequate operation level and the parameter then.

### 8.2.1 Keys

The following key symbols are employed:



#### Increment key

- Level mode: Change to parameter mode
- Parameter mode: Change to previous parameter
- Setting mode: Increment setting value



#### Decrement key

- Level mode: Change to parameter mode
- Parameter mode: Change to next parameter
- Setting mode: Decrement setting value



#### Setting key

- Enable setting value
- Change to previous level
- Parameter mode: Enable setting value
- Change and store of setting values



#### Level selection key

- Change to level mode and selection of a level
- Parameter mode: Leave mode
- Setting mode: Press key, to store data and change to base display
- In all modes: Keep key pressed for 2 seconds. Change to base display



### 8.2.2 Function Call by Keys



+



#### Auto Tuning Function

Press both keys for at least 2 seconds.

Activate and/or deactivate Auto Tuning Function (see chapter 10.6)

---



+



#### Manual Mode

Press both keys for at least 2 seconds.

Change between manual mode and control mode (automatic) (see chapter 10.2)

---



Check setting for output percentage!

---



+



#### Soft Start Function

Press both keys for at least 2 seconds.

Activate and/or deactivate Soft Start Function (see chapter 10.5)

---



Press key for at least 8 seconds

Change to parameter *PASS* (see chapter 9.5)

---



Press key for at least 10 seconds

Change to parameter *LOLL* (see chapter 9.5)





















---

## 9 Change Controller Settings








### 9.1 Operation of Parameters

After selection of the adequate operation level, the parameter can be changed as follows.


#### 9.1.1 Change of numeral value

1)					For selected parameter, press setting key to enter setting mode.
					Below value display the position indication appears, signaling by flashing (ones column, see above of  , flashing), which position of the number gets changed.
a)					On the first position from the right, the set value is incremented consecutively, when the key is kept pressed.
					If the entered value for the column exceeds 9, the next column left is incremented (limits of value range are kept).
b)					On the first position from the right, the set value is decremented consecutively, when the key is kept pressed.
2)					By pressing the setting key, the position indication can be moved from the right to the left.
					Tens column (position indication, see above  , flashing)
					Functioning method see a) and/or b)
					Hundreds column (position indication, see above  , flashing)
					Functioning method see a) and/or b)
					Thousands column (position indication, see above  , flashing)
					Functioning method see a) and/or b)
					On thousands column positioned, finish entry.
					Wherever positioned, finish entry.

### 9.1.2 Select from List of Value

					For selected parameter, press setting key to enter setting mode.
					Below value display all position indications flash (see above of  , flashing).
a)					On the display scroll forwards through the list of value consecutively.
b)					On the display scroll backwards through the list of value consecutively.
					Finish entry
					Wherever positioned, finish entry.

## 9.2 Operation Levels



If there is no operation for at least one minute, the display of the controller returns to base display of actual value/setpoint value.



Parameters, that could not be changed, but only be displayed (RO), are displayed in **gray**. The standard setting is highlighted in **green**. Parameters, that are changed by the control process, are highlighted **orange**.

### 9.2.1 Level 1 – Standard

PLE 1  
Stand

▼ ↓ ↑

°C ALR  
10

▼ ↓ ↑ ▲

°C ALR 1  
10

▼ ↓ ↑ ▲

P<sub>OPP</sub> 1 (RO)  
0

▼ ↓ ↑ ▲

P<sub>OPP</sub> 2 (RO)  
0

▼ ↓ ↑ ▲

A<sub>PI</sub> (RO)  
0.0

▼ ▲

Level 1 Standard

Actual value alarm △  
Value range: -1999...9999°C/°F

Alarm 1 △  
Value range: -1999...9999°C/°F


Output percentage 1  
Value range: 0...100%

Output percentage 2\*  
Value range: 0...100%

Current output\*  
Value range: 0...99

\*) dependent on equipment implementation see chapter 3.1

## 9.2.2 Level 2 - Control




#) See Chapter 11.3

\*) dependent on equipment implementation see chapter 3.1

### 9.3 Level 3 – Outputs

Level 3 – Outputs	
<div>PLE3</div> <div>outs</div> <div> </div>	
<div>oPF1</div> <div>HEAT</div> <div> </div>	<div>Control output 1</div> <div>HEAT Heating</div> <div>COOL Cooling</div>
<div>sCYL1</div> <div>1</div> <div> </div>	<div>Cycle time control output 1</div> <div>Value range: 0...60sec</div>
<div>oPF2</div> <div>COOL</div> <div> </div>	<div>Control output 2</div> <div>HEAT Heating</div> <div>COOL Cooling</div>
<div>CYL2</div> <div>20</div> <div> </div>	<div>Cycle time control output 2</div> <div>Value range: 0...60sec</div>
<div>ALP1</div> <div>LoHI</div> <div> </div>	<div>Alarm 1 Mode</div> <div>Value range: see chapter 11.2.1</div>
<div>ASb1</div> <div>no</div> <div> </div>	<div>Alarm 1 Standby Function</div> <div>YES Active</div> <div>no Deactive</div>
<div>°C HYS1</div> <div>2</div> <div> </div>	<div>Alarm 1 Hysteresis</div> <div>Value range: 0...500°C/°F</div>
<div>LALP</div> <div>LoHI</div> <div> </div>	<div>Actual value alarm mode</div> <div>Value range: see chapter 11.2.1</div>
<div>P noPP</div> <div>0</div> <div> </div>	<div>Output percentage in manual mode</div> <div>Value range: 0...100%</div>
<div>MAN</div> <div>no</div> <div> </div>	<div>Manual Mode</div> <div>YES Manual</div> <div>no Auto</div>

## 9.4 Level 4 – Inputs





## 9.5 Level 5 – Information

**PLES**  
Info

**Edt'n**  
PSGI

**ErrC**  
0

**PASS**  
2

**LOCK**  
188

**dPbL**  
no

**dEFL**  
no

Level 5 Information

Program version of controller

Error code  
 0      no error  
 1      Memory error  
 8      Sensor input reverse  
 16     Sensor break

Level activation  
 2      Display level 1...2  
 3      Display level 1...3  
 4      Display level 1...4  
 5      Display level 1...5  
 others Display level 1

Data locked  
 166    Setpoint value  
      changeable  
 168    Setpoint value and level  
 1      changeable  
 188    All parameters  
      changeable  
 others All parameters locked

**YES** Starts check  
**no**    Ends check

Default value  
**YES** All parameters are set  
      to default  
**no**    No

## 10 Functions

### 10.1 Set Setpoint Value

The setpoint value can be changed directly in the base display.

Prerequisite

Not any



Press button


The flashing position indication is shown below the value display.



On the first position from the right, the set value is incremented consecutively, when the key is kept pressed (limits of value range are kept).



On the first position from the right, the set value is decremented consecutively, when the key is kept pressed (limits of value range are kept).



Example: Setpoint value = 120

(arrangement of display for EC96 see chapter 8.1)



Finish entry

Entry of single positions see chapter 9.1.1 section 2)

If there is no operation for at least one minute, the display of the controller returns to base display of actual value/setpoint value. An already entered value for setpoint value is taken over.

## 10.2 Activating / Deactivating of Manual Mode

In manual mode the setpoint value instead of output percentage is displayed. As long as the controller is in manual mode, the display of output percentage flashes.

The value of output percentage can be changed directly in the base display (see chapter 10.3).


### Activating of Manual Mode

Prerequisite

Controller is in control mode.



Press both keys for at least 2 seconds.  
Manual Mode is activated.



As soon as the manual mode is activated, the display flashes, to signalize that the output percentage is displayed now and no longer the setpoint value. The current output percentage in parameter  $noPP$  is displayed.

(arrangement of display for EC96 see chapter 8.1)

Setting of output percentage see chapter 10.3.


### Deactivating of Manual Mode

Prerequisite

Controller is in manual mode.



Press both keys for at least 2 seconds.  
Manual Mode is deactivated.



As soon as the control mode is running again, the last set setpoint value is displayed. The display stops flashing to signalize, that now the setpoint value is displayed.

(arrangement of display for EC96 see chapter 8.1)


### 10.3 Set output percentage

The output percentage can be changed directly in the base display. How to change to manual mode, see chapter 10.2.

#### Set output percentage

Prerequisite

Controller is in manual mode (see chapter 10.2)



The display flashes to signalize, that now the output percentage is displayed and not the setpoint value.

(arrangement of display for EC96 see chapter 8.1)



Press button


The flashing position indication is shown below the value display.



On the first position from the right, the set value is incremented consecutively, when the key is kept pressed (limits of value range are kept).



On the first position from the right, the set value is decremented consecutively, when the key is kept pressed (limits of value range are kept).




Example: output percentage = 30

(arrangement of display for EC96 see chapter 8.1)



Finish entry



The new adjusted value (30) is taken for output percentage display as well as display in OP1.

(arrangement of display for EC96 see chapter 8.1)

Entry of single positions see chapter 9.1.1 section 2)

If there is no operation for at least one minute, the display of the controller returns to base display of actual value/output percentage. An already entered value for output percentage is rejected.

## 10.4 Display of Heating Current (only EC48)

The output current is measured by a current transformer.

The heating current is displayed as 0...20A

- in the display (without decimal place) next to AMP
- in level 1 (one decimal place) see parameter *AMP* (see chapter 9.2.1)

are shown.


The heating current is displayed proportional to the output percentage, i.e. at 100% output percentage the maximum heating current is displayed, at 50% output percentage 50% of the maximum heating current is displayed.

Example:


For a heating cartridge (1000W/230V) at 100% output percentage a heating current of ~4.35A is displayed; at 50% output percentage a heating current of ~2.18A.

Prerequisite

Not any



The heating current (example: 3.5A) is displayed in the base display next to AMP without decimal place.



The heating current (example: 3.5 A) is displayed in the operation level in parameter *AMP* with one decimal place.

## 10.5 Activating / Deactivating of Soft Start Function

The Soft Start Function is employed for careful warming of zones (baking out the moisture).

When the Soft Start Function is activated, the set value in parameter  $SFSP$  is output for the output percentage for the set time in parameter  $SFSt$ .

The controller returns to control mode, as soon as parameter  $SFSt = 0$  or the actual value  $> 120^{\circ}\text{C}$ .

### Activate Soft Start Function

#### Prerequisite

Controller is in control mode

Parameter  $SELF = no$  (see chapter 9.2.1)

Parameter  $SFSP \neq 0$  (see chapter 9.2.1)


Parameter  $SFSt \neq 0$  (see chapter 9.2.1)

Actual value  $<$  Setpoint value



Press both keys for at least 2 seconds.

Soft Start Function is activated.



To signalize, that the Soft Start Function is running, the unit flashes.

In the display OP1 the output percentage, set for Soft Start Function in parameter  $SFSP$  (example: 30 %), is displayed.

The set time in parameter  $SFSt$  (example: 1 minute) elapses.

The controller returns to control mode, as soon as parameter  $SFSt = 0$  or the actual value  $> 120^{\circ}\text{C}$ .

(arrangement of display for EC96 see chapter 8.1)

When the Soft Start Function reaches the end, parameter  $SFSt = 0$  is set.

The Soft Start Function can not be activated, as long as


- Parameter  $SFSt = 0$
- Parameter  $SELF \neq no$

For parameter  $SELF$  consider settings for PID Auto Tuning Function (see chapter 10.6).

## Deactivate Soft Start Function

Prerequisite

The Soft Start Function is running.



To signalize, that the Soft Start Function is running, the unit flashes.

(arrangement of display for EC96 see chapter 8.1)




Press both keys for at least 2 seconds.

Soft Start Function is deactivated.

Is the Soft Start Function deactivated before the normal end, the set value remains in the parameter *SFSE*.

## 10.6 PID Auto Tuning Function

By standard setting ( $SELF = E_{ur}$ ) of the controller, the PID parameters  $Pb_{-}$ ,  $I_{-}$ ,  $dI_{-}$  are calculated automatically by the Auto Tuning Function after start of the controller, when actual value is 80°C less than setpoint value. While the Auto Tuning Function is running (< 60 seconds), the indicator „ST“ flashes in display.



(arrangement of display for EC96 see chapter 8.1)

### Manual Start of PID Auto Tuning Function

Prerequisite

Parameter  $SELF = E_{ur}$

Actual value is 80°C less than setpoint value

Controller is running



Press both keys for at least 2 seconds.  
Activate Auto Tuning Function

After end of Auto Tuning Function the parameter  $SELF$  (see chapter 9.2.1) is set to  $no$ .

To have the same starting conditions for the next start of the controller, set parameter  $SELF$  to  $E_{ur}$  (see chapter 9.2.1).



## 11 Appendix

### 11.1 Trouble Shooting



Maintenance and repair work may be carried out by authorized persons only. Only skilled and on the risks trained persons may use the device. The relevant accidental regulations as well as other general approved safety-relevant, occupational-medical norms have to be obeyed.

#### 11.1.1 No Display for All Controllers

Reason	Trouble Shooting
Power supply missing	<ul style="list-style-type: none"> <li>• Check control fuse (rear side of hot runner controller)</li> <li>• Check supply of all phases</li> </ul>

#### 11.1.2 No Display for One Controllers

Reason	Trouble Shooting
Controller defective	Exchange 2 controllers against each other and check, whether the error on the alleged defective controller is still remaining. If so, exchange controller.
Wiring error	Exchange 2 controllers against each other and check, whether the error on the alleged defective controller is still remaining. If so, check wiring.

#### 11.1.3 Temperature Does Not Rise

Reason	Trouble Shooting
Fuse of zone defective	Prerequisite: setpoint value > actual value Check, current flow. If not so, check fuse of zone
Heating too low	Prerequisite: setpoint value > actual value Check, current flow. If so, the heating power is too low, i.e. install heating with more heating power.
Allocation of sensor/heating permuted	Check allocation of sensor/heating.
Sensor defective, a too high temperature value is measured	Exchange 2 controllers against each other and check, whether the error on the zone is still remaining. If so, check connecting cable and sensor and exchange defective parts.
Sensor input of controller defective	Exchange 2 controllers against each other and check, whether the error on the alleged defective controller is still remaining. If so, replace controller, otherwise check sensors.

Reason	Trouble Shooting
Wiring error	Prerequisite: setpoint value > actual value Check, current flow. If not so, wiring error possible. Let the wiring of heating be checked by an electrician.

#### 11.1.4 Temperature Too High

Reason	Trouble Shooting
Allocation of sensor/heating permuted	Check allocation of sensor/heating.
SSR defective	Prerequisite: setpoint value < actual value If temperature still rises, check SSR and exchange it.

#### 11.1.5 Temperature Not Stable

Reason	Trouble Shooting
Incorrect PID Auto Tuning or PID Auto Tuning not executed	Let the zones cool down, see 10.6.

#### 11.1.6 Difference in Temperature Display

Reason	Trouble Shooting
Wrong connecting cable	Check of the used thermocouples in the connecting cable. If not FeCuNi Type J, exchange connecting cable.
Incompatible thermocouples	Check of the used thermocouples in the mold. If not FeCuNi Type J, exchange sensor in the mold or contact supplier.
Controller defective	Exchange controller.

#### 11.1.7 Temperature Display - - - -











Reason	Trouble Shooting
Sensor input of controller defective	Exchange 2 controllers against each other and check, whether the error on the alleged defective controller is still remaining. If so, replace controller, otherwise check sensors.
Sensor break; Sensor not connected	Check the connected sensors <ul style="list-style-type: none"> <li>Remove connecting cable of hot runner controller</li> <li>Check sensor input</li> </ul> If display of ambient temperature, check connecting cable or sensor and exchange them

### 11.1.8 Temperature Display □□□□

Reason	Trouble Shooting
Check the sensor connection is not interchanged	Check the pin assignment of connecting cable and of mold.

## 11.2 Value Tables

### 11.2.1 Alarm Mode Table

Setting		Reaction
LoHI		High and low alarm
HI		High alarm
Lo		Low alarm
r-AS		Absolute alarm
r-LH		High and low alarm INVERTED
r-HI		Low alarm INVERTED
r-Lo		High alarm INVERTED
AbS		Absolute alarm INVERTED
CuLo		Current output low limit
nIL		No Alarm

▼ Setpoint Value

### 11.2.2 Sensor Types

Setting	Type	Thermo combination		Range in °C	Range in °F
J	J	Fe-CuNi	Iron copper-nickel	0...1000	0...1900
K	K	NiCr-NiAl	Nickel-chromium nickel-aluminum	0...1200	0...2450
t	T	Cu-CuNi	Copper copper-nickel	0...400	0...730
S	S	Pt10Rh-Pt	Platinum-10% Rhodium Platinum	0...1700	0...3200
r	R	Pt13Rh-Pt	Platinum-13% Rhodium Platinum	0...1700	0...3200
E	E	NiCr-CuNi	Nickel-chromium copper-nickel	0...800	0...1300
dIn	Pt100	ITS		200...600	200...1000
JIS	Pt100	JTS		200...600	200...1000

The standard setting is highlighted in green.




When another sensor type is used, the compensating cable must be adapted.

### 11.3 Cooling Output

To protect the cooling output (type KSR) and in case a mechanic relay is connected, before changing between status ON after status OFF, wait a short time.

By the parameter for the minimal OFF time  $\text{CLdY}$  and the minimal ON time  $\text{CLoT}$  the cooling output can be configured.



Recommended setting

$\text{CLdY} = 1$

$\text{CLoT} = 1$

## 11.4 Version History

Version	Date	Changes
1.00.00	03-31-2010	First edition PSG Plastic Service GmbH Pirnaer Straße 12-16 68309 Mannheim Germany Tel. +49 621 7162 0 Fax +49 621 7162 162 www.psg-online.de info@psg-online.de